Newflow

P587 OmniBuss

User Manual



Contact:

Newflow Ltd Unit 4B, 21 Cherry Farm Close Malton North Yorkshire YO17 6AW, UK

Tel: +44 1653 31 00 00 Email: sales@newflow.co.uk

Document Information

Document Name: P587 OmniBuss User Manual

Document Identifier NF_OmniBuss-UM

Rev	Date	Changes	Prepared	Checked	Authorized
0	13 Jan 2022	Original	MOB	DGS	MOB
1	10 Nov 2022	Minor typos & format changes	MOB	DGS	MOB
2	15 Dec 2025	New Office Address. OmniBuss version 0.5.3.1	MOB	DGS	GPL
3					
4					

All trademarks are acknowledged as the property of their respective owners.


This document, submitted in confidence, contains proprietary information which shall not be reproduced or transferred to others without prior written permission of Newflow Ltd.

This document shall not form part of any contract. Specifications are subject to change without notice and Newflow Ltd accepts no liability of any kind for errors or omissions.

© Newflow Ltd 2025

Full contractual terms are available on the website at $\frac{www.newflow.co.uk/pdf/tandc.pdf}{MMXXV}$

Spreadsheet Source Data



OmniBuss Screenshot




Table of Contents

1	Introduction	5
	Installation of OmniBuss	
	Licensing the OmniBuss program	
	Loading Information into OmniBuss	
	Pre-Loading a NÅNO Prover Computer	
	Network Settings	
	Managing the Source Information	
	7.1 Exporting the Information from LibreOffice	
	7.2 Exporting the Information from Excel	
	Debug Information.	

1 Introduction

OmniBuss is a highly versatile Windows program which can be used to pre-load constants or settings into a NÅNO.

The OmniBuss program needs to be registered in order to be able to import the Provers or Customers files, but it can be demonstrated using default Provers and Customers data.

The source information can be maintained in a spreadsheet, for ease of management. Any spreadsheet can be used, Libreoffice is ideal, but Excel is also suitable.

The sheet data has to be exported in a tab separated values format with a .tsv , .csv or a .txt extension.

File editing is NOT provided in OmniBuss, as this could lead to inconsistent data sets across an organization. The data can be viewed and transmitted to the Prover Computer, but any changes to the information must be done to the source files, although any data pre-loaded into a NÅNO Prover or Flow Computer can be overwritten using the NÅNO web interface, should on-site changes be required.

The source information can be imported from spreadsheets using a tab separated values format with a .tsv , .csv or a .txt extension.


The OmniBuss program builds a SQLite .db3 database, and this database can be directly modified, if the user has sufficient SQLite database knowledge, contact your distributor for more information.

2 Installation of OmniBuss

The OmniBuss program is a single executable program that does not require any DLL's or other additional Microsoft files to operate, so does not require an installer. The file can be placed in any folder or directory, including the desktop, a USB memory stick or a network drive.

If you have purchased a pre-authorized version of OmniBuss, it will also be supplied with a custom config.ini file, which must be located in the same folder or directory.

When OmniBuss is first launched, it will check to see if there is a valid config.ini file in the same folder or directory. If the file is not found, it will generate a default config.ini file and display the message shown below.




If a valid config.ini file is found, an initial OmniBuss.db3 database file will also be created in the same folder or directory and the main OmniBuss window will be opened as shown below.

The Banner shows the program name and version number (v0.5.0.11 in this case) and states who the software is licensed to. If it is not currently licensed, then it will state Demo Mode as in the example shown below.

The top row of menu selections are File, Network and License.

Below these pull down menus, there are four tabs.

These are Prover Selection [xxxx], Meter Selection [yyyy], Device Selection and Tag Details. These menus are full explained later in the manual




3 Licensing the OmniBuss program


OmniBuss can be run without being licensed in order to demonstrate the functionality, however you will not be able to import the Prover or Meters information and only use the demo data included. This is sufficient to allow the process to be tested.

If OmniBuss has been purchased, your distributor will also send a config.ini file, which must be located in the same folder or directory as the OmniBuss.exe file.

Alternatively, click on License in the menu bar, and then click on details.




This will open the license details dialog box



To request a license, fill in the name that you want to appear on the prover reports and the top banner of the OmniBuss program, in the orange box shown above, and click Gen(erate) Request Key. This will fill in the Request Key field, and copy the contents into the clipboard, so it can be pasted into an email.

Do NOT use the name UNREGISTERED as the operator name, as operation may be indeterminant.



Send the Request Key by email to your distributor, and they will return the Unlock Key.


Compare Details - Compare D	Registered to ACME CALIBRATION SERVICES		×
Operator Name	ACME CALIBRATION SERVICES	Gen Request Key	
Request Key	tm9=kSyi\x:RKAnM`ak7XAgdidRB8	Сору	
Unlock Key	xj 5Qd [Msl ^]lı dyN3 Dg?F`F	Set Key	

Paste the Unlock Key into the lower entry box and if valid, the Operator Name field will change to a green background and Set Key button will appear. Clicking the Set Key will save the licensing details in the config.ini file.


4 Loading Information into OmniBuss

Double click the OmniBuss executable file to launch the program.

The screenshot below shows OmniBuss after it has been registered. The demo mode Provers and Meters shown in demo mode are removed, but no "real" data has been imported




To import data, click on File on the menu bar, and then select Import Provers/Meter from the choice show.




Clicking on Import Provers/Meter will open the standard windows explorer window, and you can now select the tabulated data for the provers and the meters.

NOTE: You need to select the appropriate import type. We recommend that from Excel you export as a Text (Tab delimited) file (*.txt) and from all other spreadsheets, such as LibreOffice, select *.csv




You can select both the Prover information file and the Meters information file at the same time (using the control – Ctrl key, and then click the Open button.



The dialog lists the number of Meters and Provers imported.


If when the Open button is clicked, the I/O Error dialog is shown, the file you have selected is probably still open in another application, such as the spreadsheet program. Once the other program has been closed, repeat the import process.




5 Pre-Loading a NÅNO Prover Computer

Once OmniBuss has been registered, and the Provers and Meters information loaded, the program is ready to go.

The initial view will show the Prover information loaded. Click on the line containing the Prover to be used, and the whole line will show a blue background, and the name in the Prover Selection Tab will show the Prover Tag Name, CalSVP123 in the example shown below.




Now click on the Meter Selection tab. And again, click on the line containing the meter to be proved.




The Meter Selection tab now shows EPP25/123, confirming the Meter information.

If there are very many entries entries in either of the first two tabs, then the filter can be used to reduce the clutter, to make selection easier. In the example below, all fields are being checked for the entry "co" and this has found the word "Coriolis" in the meter Type column.




If a finer search is needed, then the filter can be applied to just one of the table headings. For example, if the Meter Location happened to contain the word "Colorado", then the search for a line containing "co" would also shown these line as well as those with the word Coriolis. However if you click on the down arrow symbol in the filter box currently displaying ANY FIELD you can then filter by individual column only, by selecting the appropriate filed name.



Now that the Prover and Meter have been selected, this information needs to transmitted to the prover computer. Click on the Device Selection tab, and this will show all devices on the network. In many instances, there will only be one device accessible, and this will be selected by default.

NOTE: If the network has not been used before, the network interface must be selected. Most desktop machine only have one network interface, however laptops almost always have at least two, a wired Ethernet and a Wi-Fi card. The appropriate interface needs to be selected, otherwise OmniBuss will report that No Units (Devices) have been detected - Check Network Settings.

See <u>Section 6. Network Settings</u> for further information on connecting to the network




The Prover has been selected, the Meter has been selected and the Proving Computer Device has been selected. Note for the first time you connect to a device, you need to know the username (user) and password (Pwd) in order to load the data.

NOTE: The username and password are stored in an encrypted format by OmniBuss for all future operations. This information is entered in the fields shown below. The Port number should not need to be changed.




To pre-Load the proving computer, click the **Pre-Load Device** button. A dialog box will pop up to confirm the Prover, Meter and Device selection.




Click the Yes Button, and the data will be transferred. If any errors occur, they will be reported.

6 Network Settings

If no network has been detected, the screenshot below shows the Device Selection Tab




To select the appropriate network, click the "Network" text on the menu bar, and select the appropriate network controller. As soon as the network controller is selected, OmniBuss will look for available devices.



If there is only one device available, it will have already been selected. Right clicking on the line showing each device brings up a submenu, relating to the selected line.


NOTE: If the Network settings are changed whilst OmniBuss is running, simply close the program and re-open it.



Choosing the "start Web Interface" option will launch the default web browser (Firefox recommended) and preset the IP address to the device selected.

Clicking the "Strobe Ident Lights" will cause the selected device to flash the ident light so that the unit can be physically identified.

Clicking the "Configure" option will open a network configuration dialog box.



7 Managing the Source Information

OmniBuss imports data in tab delimited format. There needs to be two files, one for the Provers information and one for the Meters information.

We recommend that the file name contains the word Provers or Meters for the convenience of the operators.

	Α	В	С	D	E	
1	Provers					
2	Field	Туре	PtagName	Manufacturer	Model	Serial
3	Title	Prover Type (SVP, BALL)	Prover Tag Name	Prover Manufacturer	Prover Model	Prover Se
4	TagNam		FCSVPRVtagnam	FCSVPRVmaker	FCSVPRVmo	FCSVPR\
5	1	Small Volume	SVP001	FMD	FMD007	1234/FGT
6	2	Small Volume	SVP002	FMD	FMD077	4321/FGT
7	3	Small Volume	SVP003	FMD	FMD777	1111/FGT
8	4	Small Volume	CalSVP123	Calibron	CLB200/45	CLB2-555
9	5	Small Volume	CalSVP124	Calibron	CLB300/12	CLB3-666
10	6	Small Volume	CalSVP125	Calibron	CLL444B	CLB4-777
11	7	Bi-Directional	ME_555-TAG1	Meter Engineers	CLL555B	CLB4-888
12	R	Ri-Directional	MF 666-TAG2	Meter Fngineers	CLI 666B	CI R4-999

The top row must have the word Provers or Meters in the first cell.

The second row contains the names used to construct the SQLite DataBase, and must NOT be edited.

The third row contains the names of the fields, which are displayed in OmniBuss.

The fourth row contains the XML TagNames that are used to connect to the NÅNO Prover Computer, and again must not be changed.

The fifth and subsequent lines contain the user information.


The tab separated value files can be generated or edited in a variety of different ways, but using a spreadsheet program is a simple solution.

We have provide templates in both .ods format for LibreOffice, OpenOffice and many other open standards compliant spreadsheet programs as well as a .xlsx for use with Excel.


NOTE: The use of the spreadsheet templates is highly recommended, as the top row and the second row are hidden (as they are not relevant to any user or operator) and the third and fourth rows are visible, but protected.

7.1 Exporting the Information from LibreOffice

LibreOffice is an open source spreadsheet program that runs on Linux, Apple Macs and Windows computers. It is entirely free to use, and there are no licenses to manage. The interfaces are clear, and it is not changed as the whims of fashions change.



To export from LibreOffice, Click File on the menu bar and click on Save As from the options displayed. The message shown below will be displayed. Choice the Use Text CSV Format option




Once you have confirmed the data type, a second dialog box will open to set the export parameters.


Select a Western Character Setting

The Field delimiter should be a TAB or a Comma character.


The String delimiter must be double quote character (")



7.2 Exporting the Information from Excel



Go to the File menu and select export. Then choose the Text (Tab deliminated) (*.txt) option




and save the file as a text file.

NOTE: Excel has the horrible feature that it switches to the exported file, so ensure to save the file BEFORE exporting the data.

8 Debug Information

The Tag Details tab is only used if there is a mismatch between the pre-loaded data and the Proving Computer application, and is not required in normal operation.



END OF OmniBuss USER MANUAL